

LUDLOW

1-800-621-6024

For sales or service: **1-800/621-6024**

Ludlow Typewriter Photo Polymer Platemaker
Direct Stripcaster Lettering Machines
Ludlow Matrices & Slits Graphic Arts Accessories
Kajira Electronic Keyboard Type Processor

LUDLOW TYPOGRAPH COMPANY, Division of Ludlow Industries, Inc.
9801 West Belmont Rosemont, IL 60018 312/601-6000

102 L ST.

Anniston AL 36201

Tom

MODEL **M** Ludlow

Serial # 10916615

MANUAL OF INSTRUCTIONS AND PARTS LIST

1-800-621-6024

Kevin



MODEL M LUDLOW

Branch Sales Offices:

NEW YORK 589 Fifth Avenue

BOSTON 200 Summer Street

ATLANTA 120 Marietta Street

SAN FRANCISCO 760 Market Street

**installation
maintenance
adjustments
illustrations
and parts list**

LUDLOW TYPOGRAPH COMPANY

2032 Clybourn Avenue, Chicago, Illinois 60614

5976 North Northwest Hwy
60631

Cable Address:

LUDTYPE, CHICAGO

THE UNIVERSITY OF CHICAGO
LIBRARY

Installation
Maintenance
Adjustments
Illustrations
and parts list

HANDBOOK FOR LUBRICATION

1950 Edition
Copyright 1950 by The University of Chicago
Library of The University of Chicago

1950

UNIVERSITY OF CHICAGO
LIBRARY

Installation of the Model M Ludlow

The Model M Ludlow machine should be placed at the front and center of a space approximately 5' x 7'. This will allow ample room for the machine and the water cooler as well as working space at the sides and at the back of the machine for cleaning, oiling and adjusting. The operator works in front of the machine, where additional space must be allowed for efficient operation.

Electrical Connections

For electric-heated machines, the power wires are connected to the control panel located on the back of the machine. A No. 10 gauge main power supply wire is recommended.

Gas Connections

For gas-heated machines, a $\frac{1}{2}$ inch pipe is used. This should be connected to a supply line of sufficient capacity to prevent pressure fluctuations.

Proper Seating and Leveling of the Model M Ludlow

The Ludlow should be placed on a metal plate, preferably on the Ludlow Metal Floor Pan, part No. 27, which is supplied as an accessory. In placing the Ludlow in position it is very important that the legs are "even" and do not create a twist in the frame, which could cause a bind in the main slide as well as lock-up problems.

To properly seat the Model M Ludlow machine:

1. Lift table top to full open position.
2. Apply pressure on a corner of the table and note which leg is not seating firmly on the floor pan.
3. Insert metal shims under one foot opposite the motor side of the machine until the weight is evenly distributed on all four feet.

An alternate method of seating the machine is:

1. Raise the left leg of the machine $\frac{1}{2}$ inch off the floor by means of a jack or block and wedge placed under the cross member of the left leg.
2. Place a piece of paper beneath each foot of the left leg.
3. Lower the machine until one of the papers is lightly gripped by one foot. Then place shims of leads or shap under the opposite foot. Do not force shimming material in place.
4. Remove the jack or block and wedge.

To properly level the machine from front to back:

1. Return table top to normal position and place a spirit level on the table top from front to back.
2. An equal amount of metal shims should be placed under each of either the front or rear feet of the machine until the table top is approximately level from front to back.

The back of the machine must not be lower than the front. It may be $\frac{1}{4}$ inch higher.

Assembly

For safety in shipping, certain parts are packed separately and these should be installed on the machine as follows:

1. Place crucible in position, insert hinge pins through swivel bracket and tighten set screws.
2. Install Plunger Connecting Rod, part No. 270-BA. Note: When shipped from the factory, the plunger is "loose" in proper position in relation to the porthole in the wall. When properly installed the plunger connecting rod will be in position so that the Plunger Connecting Yoke Pins, Nos. 275 and 280, can be inserted in place without forcing. Tighten lock nut at the bottom of the plunger connecting rod.
3. Attach control panel to bracket on back of machine and make necessary electrical connections according to wiring diagram.
4. Place the water cooler on the floor at the rear of the machine. Connect the water tubes to the cooler. Attach the tubes to the frame of the machine as shown in the diagram. Connect electric wires to the power connections at the motor so that when the motor of the machine is "on" the cooler will be in operation.
5. Install Mold. Be careful to thoroughly clean mold seat and bottom of mold before fastening in position. Tighten mold screws firmly in position.
6. Fill water cooler at top with approximately two gallons of water. (Distilled water is preferred.) Add between one and two ounces of soluble oil. Bleed air from

system as per tag on water cooler. Connect water tubes to mold.

7. Other parts which were removed from the machine to save shipping space, such as the Galley Base, A-505-B, the Locking Lever Handle, No. 547, the Delivery Side Guard, etc. should then be attached to the machine.
8. Fill the crucible with type metal, molten if possible, to completely cover heating units.

9. Except in the case of some export shipments, the motor is mounted in place with motor lead wires connected. The motor pulley should be placed on the shaft and lined up with large pulley. The set screws in the pulley should bear against the flat surface of the motor shaft and should be firmly tightened. The motor position can be adjusted from front to back of machine to insure proper tension on the belt. The motor armature must rotate in a counter-clockwise direction when facing the motor pulley.

10. While the crucible is heating out, turn large pulley by hand until machine is in casting position. Check the following adjustments:

Mold slide height adjustment

Table latch adjustment

Stick locking mechanism adjustment

Mouldpiece to mold adjustment

Crucible adjustment

Crucible raised adjustment

Crucible compression adjustment

Centering of the mouldpiece spacing with the mold. Instructions for checking adjustments referred to above are shown in the "Adjustments" section of this manual.

Maintenance

It will be apparent to even the most casual observer that the Ludlow Typograph machine is of rigid construction, has relatively few moving parts, and that the few simple adjustments that may be necessary to maintain its satisfactory operation are easily made.

Oiling

The Ludlow Typograph machine should be thoroughly oiled twice each week, excepting the motor. New motors are oiled and inspected at the factory and, for normal service, should not need additional oil during the first year. Add 40 to 70 drops of a good light oil (SAE-20) or medium (SAE-30) mineral lubricating oil at the end of six months use, if used on a double shift, or at the end of one year if used on a single shift, or after 1,000 hours of service. Over-oiling is as undesirable as under-oiling.

The operator should make a practice of oiling the machine systematically, starting from the same place each time. By going through the same routine, only a few minutes will be required to lubricate the machine thoroughly.

The oiler in the rear of the Crucible Can Lever, 224ED, should be filled each day with Ludlow Lubricious Fluid, 4245A. Use Lubricious for all moving parts on the crucible which are subjected to heat, as this is a special preparation

which will remain on the heated parts for a longer period of time than will ordinary lubricants.

The Felt Mouthpiece Wiper, 80GD, is treated with a special lubricant and should not require any additional oiling.

Ordinary oil is not recommended for the felt wiper, as it will carbonize and fill the mouthpiece air vents and obstruct the opening of the mouthpiece with a deposit which is difficult to remove.

Maintenance Schedule

Every day: Oil Crucible Can Lever, 224ED. Add oil in oilers and oil holes. Oil cans and can rolls with "seal-it" can.

Twice a week: Clean plunger and well.

Once a week: Clean entire machine.

Twice a month: Remove mouthpiece and clean mouthpiece and throat.

Cleaning the Plunger and Well

Free movement of the plunger in the well is dependent upon the thorough cleaning of these parts at least twice each week or oftener. A Plunger and Well Cleaning Kit, A951, is available for this purpose.

When cleaning the plunger and well, cover the mouthpiece

with the Mouthpiece Opening Shield, A504, to prevent the hot metal from splashing out of the mouthpiece when the plunger or well cleaning tool is being inserted into the well.

To clean the plunger, remove it from the crucible, using the combination Holder for the Plunger and Crucible Well Cleaner, A992A. While the plunger is still hot, wipe off the metal and loose deposits adhering to the outer surface and apply a light application of Lubricum Fluid with the asbestos wand. Allow the fluid to remain on the plunger approximately two to three minutes before breaking off with a wire brush and wiping clean with a cloth. If a hard deposit in the form of a ring is noticed on the upper area of the plunger, it can best be removed with a strip of fine emery cloth.

Immediately after removing the plunger from the crucible for cleaning, place the Crucible Well Cleaner, A992 $\frac{1}{2}$ A, in the molten metal of the crucible (not in the well), to allow the tool to preheat to the temperature of the type metal, as it will be ready for immediate use when the plunger has been cleaned.

To clean the well, skin down loose surface of metal, assemble the preheated well cleaning tool to the holder, A992A. Drop it or 10 drops of Lubricum Fluid in a pool on top of the metal immediately over the well and insert the cleaning tool in the well and work it in an oscillating and up-and-down motion. The oil on the surface of the metal will transfer to the cleaning tool and keep it lubricated. Remove the cleaning tool frequently to wipe off the dross, continuing this operation until the well is cleaned. If the well has not been cleaned regularly, it may be necessary to apply the fluid to the top of the metal two or three times during the cleaning operation.

Before replacing the plunger in the well, skin the dross and Lubricum residue from the surface of the type metal. Apply a thin coating of Lubricum to the plunger, and see that it floats freely in the well before assembling it to the plunger lever.

Care should be taken not to drop or bump the plunger or the well cleaning tool against a hard object, as this may wear or upset the surface of these parts, with resultant damage to the well.

If the well cleaning tool becomes ineffective, the four segments can be expanded slightly by careful use of a screw driver or like tool to spring the segments further apart.

Special patented preparations and tapers should be avoided as a lubricant or cleaner for plunger and well.

Failure to keep the plunger and well clean will invariably result in an unsatisfactory printing face and porous slugs.

Care of Mouthpiece

The grayish-black deposit which accumulates on the vented surface and in the slot of the mouthpiece can easily be removed when hot by the use of Lardex Lubricum Fluid. The fluid is applied on the vented surface and in the slot of the mouthpiece and allowed to remain for two to three minutes, when the slot may be scraped clean with the Mouthpiece Slot Scraper, A555B. The three holes in the mouthpiece may be cleaned with a piece of wire $\frac{1}{16}$ inch in diameter. If necessary, the surface may be carefully brushed clean with a wire brush before removing mouthpiece for a thorough cleaning of the throat.

It is advisable to remove the mouthpiece from the crucible at least twice a month to clean the lower part of the mouthpiece and to scrape the side walls of the crucible throat. When cleaning the crucible throat, reduce the metal level by heating until the top of the well is exposed. To prevent molten metal from entering the screw holes, it is best to replace the mouthpiece screws before scraping the throat of the crucible. With the crucible prepared as above, the Crucible Throat Scraper, A555 $\frac{1}{2}$ B, should be used to scrape the walls of the throat.

After scraping, remove all loose dross from the throat before reassembling the mouthpiece to the crucible. When assembling the mouthpiece to the crucible, the screws should

be treated with graphite, to insure their easy removal. No graphite should be put into the screw holes. After the mouthpiece has been assembled to the crucible, cast several blank slugs to thoroughly clean the throat before casting typeface slugs.

Metal Level in the Crucible

Always try to keep metal level approximately $\frac{1}{4}$ inch to $\frac{1}{2}$ inch below the top of the front of the crucible. If the metal level is permitted to drop below the top of the heating elements, these elements, when heated, can be damaged by their exposure to the air. A low level will also have considerable effect on the solidity of the slug. The metal level may be accurately regulated by the use of an automatic metal feeder.

Care of the Metal

To secure best results, high quality metal should be used in the Ludlow, as in any line-casting machine. Metal which contains improper proportions of lead, tin and antimony, or which is contaminated with copper, zinc, or other foreign substance, will cause considerable trouble. An indication of this trouble will appear in a poor printing face on the slug. In some cases these impurities will form obstructions in the throat and mouthpiece and make it impossible to obtain a satisfactory slug. Any of the leading metal companies will gladly furnish an analysis of the metal from a sample and will advise you of its condition. About a pound of metal will be necessary for proper analysis and this sample may be obtained by casting blank slugs.

It is not intended that any metal other than either standard Ludlow or standard Linotype metal be used in the Ludlow machine. Standard Ludlow metal contains 6% tin, 11½% antimony, and the balance lead. Standard Linotype metal contains 4% tin, 11½% antimony, and the balance lead. Trouble may be expected when the tin drops below 3½%,

or when the antimony drops below 11½% or goes over 12%.

Type metal should not contain copper or zinc, and only a trace of arsenic.

Metal Temperature

For standard Linotype metal the temperature of the metal in the crucible under normal conditions should be 565° F. For standard Ludlow metal the crucible temperature may be increased from 5° to 10°. The temperature at the mouthpiece under normal conditions will be 530° with a 6-pt. mold and 508° with a 12-pt. mold. It is important to note that these temperatures are approximate and of necessity must vary depending upon the condition of the metal and other local conditions including line voltage, etc. The temperature must be adjusted to obtain best results in each individual case.

Machine Must Be Kept Clean

The greatest cause of trouble results from failure of the operator to keep his machine clean. As with all hot metal machines, satisfactory operation depends upon perfect contact between matrices, mold and mouthpiece. If particles of metal or other foreign material adhere to the mold, the mouthpiece or the matrices, this perfect contact will not be maintained; or if particles of metal, such as trimmings, etc., become lodged in the case, trouble will inevitably result.

The foreman in charge of a Ludlow Typograph machine will find that if some one person is made responsible for the maintenance of the machine and is allotted a certain time each day for this work, his effort will be repaid many times by increased production and freedom from repairs and replacements.

The operator should be provided with a stiff bristle brush to remove the particles of metal from the working parts, such as the case, slides, etc. This should be done frequently. At least once each week the operator should clean the entire machine and remove all accumulations of dust and metal trimmings.

Care of Matrices and Spacers

Loose matrices and spacers should be handled carefully at all times. Rough handling will shorten the life of matrices and spacers and cause the slugs to stick to the matrices in the casting operation, due to burrs on the face notch of the matrices. Improper gathering, the "flicking" or "snapping" of matrices on the sides of the stick or against each other, rough handling

of the matrices and stick on the table top will shorten the life of the matrices and spacers and cause difficulty. When tightening the matrices in position before casting, the knob on the stick should be tightened only tightly enough to hold the matrices in position but not so tightly that the mold and equalizing bar cannot equalize the height of the matrices before the slug is cast.

Adjustments

When the machine leaves the factory, all of its parts have been tested and properly adjusted. However, after the machine has been in use for some time, it may become necessary to readjust some parts. The following instructions should be closely and carefully followed:

Safety Mechanisms

Before making any adjustments, unlatch and raise the table with the hand lever on the left side of the machine. See that the Safety Finger, 735A, is over the end of the Plunger Cam Lever, 425B. When the safety finger is in this position the plunger will not operate should the machine be turned on.

The Locking Slide Safety Pad Bumper, 549C, is so designed that if the end quad on the stick or the direction quad does not strike the bumper, the stick cannot be locked in place. The operator should see that this bumper does not become clogged with dirt or metal that might interfere with its operation.

The Locking Slide Safety Pad, 579B, is so arranged that the stick of motion must be pushed against the stick stop before the stick can be locked in place to make a cast. This pad should also be kept clean and free from dirt or metal that might interfere with its operation.

The Safety Operating Lever, 738B, is connected to the

locking-down mechanism and operates the Safety Finger, permitting a cast to be made only when the stick is properly locked in position. This is an important safety feature, and care should be taken to see that these parts and parts connected to them, such as 735A, and parts 732B and 735A, and all of their attendant mechanisms are in perfect operating order. Particular attention should be given to Spring, 725, which is located on the under side of the table top, and to Spring, 509C, (inside of tube), attached to the lower part of the mechanism just inside the frame in front of the crucible. These springs keep the safety mechanism in the non-casting position, and the machine should never be allowed to operate without them. Always observe the condition of these springs before making any other adjustments or repairs.

Safety Key

The Safety Key, 155R, which connects the Driving Clutch Gear, 154A, with the Driving Clutch Shaft, 163R, is of such construction that any obstruction to the free turning of the machine will shear the safety key, thus safeguarding against breaking expensive parts of the machine. When this key shears off, replace it with a new one and "back up" the machine in order to locate and correct the cause of the shearing. Quite frequently this shearing will result from insufficient

lubrication, dirt or metal trimmings accumulating in the runs, or by trimmings wedging in between the bottom trim knife slide and the main slide casting. It may also be caused by metal splashing out between the mouthpiece and mold, due probably to improper lock-up or by the failure of the mouthpiece wiper to clean off the mouthpiece properly. After the obstruction is located and removed, operate the machine carefully by hand to be sure that the cause of shearing the safety key has been corrected.

Main Slide Height Adjustment

To test the height of the Main Slide, 680, to which the mold is attached, first remove the right Safety Lever Screw, 736A $\frac{1}{2}$, and disconnect Safety Connecting Rod, 743B, then remove Table Latch Operating Stud, 77, and then raise the main slide to the highest point of its travel, but do not have the mouthpiece in contact with the mold. Place a blank slug on top of the mold without being locked down, and see that the sides of the blank slug block are two points above the surface of the table top. Any adjustment of this height is made as follows:

Raise the table top, remove the belt pulley by hand until the main slide has reached the highest point of its travel, but do not have the mouthpiece in contact with the mold. Loosen the Main Slide Adjusting Plate, 612A, located directly under the right hand side of the main slide, by means of Screw, 612A, using Wrench, A625 $\frac{1}{2}$, furnished with the machine. Using two $\frac{3}{4}$ inch x 4 inch drill rods for screwdrivers, loosen the two Check Nuts, 615 and 616 $\frac{1}{2}$, and turn Adjusting Screw, 614, to either raise or lower the main slide. After the proper adjustment is made, carefully tighten the two check nuts and Adjusting Plate Screw, 612A.

Reassemble Safety Mechanism parts.

Blank Latching Mechanism Adjustment

First, recheck blank table latch adjustment. Second, loosen two lock-down knobs on the table top to hold it firmly to

main frame. Remove the Safety Connecting Rod, 747B. Then operate the machine by hand until the mouthpiece is in approximate casting position under the mold, but is still $\frac{1}{4}$ inch away from the mold. Lock the blank slug block in position. Loosen Clamp Screws, 18, which is on the side of the Locking Equalizing Bar Clamp, 588A. Back out Adjusting Screw, 583A, until the rollers are free of the locking equalizing bar. Remove Locking Equalizing Lever Adjusting Screw Cap, 593 $\frac{1}{2}$, and loosen the Check Nut, 256, on the Locking Equalizing Screw, 393, and back the adjusting screw until the Locking Equalizing Bar, A590C, is free of the blank slug block. Then turn this screw, at the same time tapping the top of the equalizing bar with the finger until the equalizing bar makes full contact with the top of the blank slug block. Adjust rollers to bearing contact on the equalizing bar. Tighten all clamp screws after these adjustments have been made.

Blank Stop Adjustment

The blank stop should be so adjusted that when a line is cast the head of the slug is exactly even with the shank of the slug on the end farthest from the operator. This adjustment may be made by loosening the small Set Screw, 713A, in the top of the stick stop slide and turning the Adjusting Screw, 714, in or out until the proper alignment is obtained, after which tighten the set screw. Check this adjustment by casting on either line, using the same stick.

Locking Slide Adjustment

When a stick of material is placed in the machine and locked in position, it is pushed against the Locking Guide, M575B, by the Locking Slide Shoe, 567, and the spring tension of the two Locking Slide Shoe Springs, 568. These springs sometimes become weakened after long usage and require replacement. If the head of the slug is not parallel to the shank, it may be that these springs do not have sufficient tension to hold the stick of material firmly against the lock-

ing guide at the time the cast is made, or that the locking guide itself is out of alignment.

The locking guide is adjustable so that the proper alignment of stick may be maintained at all times. To make this adjustment, the Locking Guide Screws, 376A, should be loosened, which will permit the turning of the Locking Adjusting Screws, 322B. Very little movement of these screws will be necessary to obtain the proper adjustment. Tighten the Screws, 376A, while the stick is locked in position.

If the locking guide has been put out of adjustment to the extent that the Locking Slide Safety Pad Bumper, 549C, does not operate properly, it will then be necessary to realign the guide from the mold slot. To do this, disconnect the Safety Connecting Rod, 747B. Remove Locking Equalizing Bar, A559C. Loosen the locking guide. Then raise the Main Slide, 689, to the highest point of its travel. Place a blank slug halfway into the mold slot. The distance between the blank slug and the locking guide should be 5/16" plus (.004") when using a 12-pt. mold, and 5/16" plus (.006") when using a 6-pt. mold.

Mouthpiece to Mold Adjustment

Reverse the lock pulley by hand until the mouthpiece is ready to come into contact with the mold. Slip a piece of paper between the mouthpiece and the mold and operate the machine by hand until the mouthpiece is locked up against the under side of the mold; then back up the machine a little until the paper may be removed. The impression on the paper will show whether the mouthpiece is seating solidly and evenly against the mold.

There are two ways in which the mouthpiece may be out of adjustment with relation to its proper seating against the under side of the mold. First, the crucible may be tilted side-wise in such a way that the mouthpiece bears against the mold only along one side, and this condition is referred to in this section. Second, the mouthpiece may bear against the mold

more on one end than on the other, the correction for which is explained under "Crucible Adjustment."

At the rear of the machine and located directly under the crucible, is the Crucible Swivel Bracket, 234H, fastened to the frame by two Screws, 234. Make sure the mouthpiece is not touching the bottom of the mold, loosen only one of these screws slightly and then loosen the Check Nut, 59, and turn the Adjusting Screw, 237, which will tilt the crucible in the desired direction. Very little movement of the screw is necessary—perhaps not over one-eighth turn. Make the test with the paper again to be certain that the adjustment is correct. The paper should show an even impression of both sides of the mouthpiece seat. Then tighten Screw, 234, and the Check Nut, 59.

After tightening the screw and nut, test the lock-up again. It may be necessary to adjust the opposite side of the crucible swivel bracket.

Crucible Adjustment

Check stick locking mechanism and rear table latch to be sure they are properly adjusted.

In the upper right-hand corner of the illustration are two kinds of incorrect seating relations between mouthpiece and mold. These may be corrected by either lowering or raising the Crucible Swivel Bracket, 234-B, as follows:

Note: Do not loosen lock screws 236 at same time.

To remedy "A" condition

Make sure the mouthpiece is not touching the bottom of mold when making the following adjustments.

Loosen screw 236 (left side only facing rear of machine) enough so screw bears slightly on Bracket, 234-B. Loosen Check Nut, 59, and turn screw 237 slightly to the left. Tighten screw 236 and nut 59.

It may be necessary to repeat above on right-hand side until proper seating is accomplished.

To remedy "B" condition

Same as above except work first on right side facing rear of machine and turn screw 237 to the right.

Very little movement of these screws will be necessary to correct the seating relations of these parts. To determine just when the mold and mouthpiece are in proper relation, insert a strip of tissue paper between the under side of the mold and the mouthpiece and move crucible to the casting position. The mouthpiece should leave an even impression on the paper, indicating that the mouthpiece is pressing against the mold equally on both ends. Check the Compression Bolt, 212-B, to see that the Castellated Nut, 214-A, is raised $\frac{1}{16}$ inch above its seat when in casting position as indicated at "C". Adjust if necessary. Cast a few slugs, preferably 12-pt., using the blank slug block. If the mouthpiece and mold are properly adjusted, the mouthpiece vent marks will show up clearly along bottom of the slug over its entire length. If the mouthpiece and mold are not in proper relation, the vent marks will be only partly visible and the bottom of slug will be shiny, either wholly or in part. While casting test slugs, the mouthpiece should be wiped off carefully between each cast. If one end of the slug bottom is consistently shiny, it indicates that the corresponding end of the mouthpiece should be raised slightly.

Great care must be taken in making this adjustment. It will probably occur be necessary to move adjusting screws 237 over one half turn.

Refer to illustration of Crucible Operation Mechanism. See that both Crucible Swivel Bracket Screws, 238, and Check Nuts, 59, are tight.

When adjustments are performed properly, there will be a slight gap between screws 237 and the bracket. The point of the screws will be seated against bracket on left side, and the head of the screws on right side. After these adjustments have been taken care of satisfactorily, turn two Adjusting Screws, 1231 $\frac{1}{2}$, of Swivel Bracket Lock, 234 $\frac{1}{2}$, so that they bear

against 234-B bracket. Then tighten lock screws 623 $\frac{1}{2}$ of the adjusting screws.

Crucible Swivel

The Crucible Swivel Nut, 232, should be just tight enough to resist any tendency of the crucible to rock, yet not so tight that it offers resistance to the turning of the Crucible Swivel, 231-B. To adjust this nut, with crucible at rest position, remove the Crucible Swivel Nut Pin, 233, and turn this nut, using a metal rod, to the right to tighten, or to the left to loosen, after which replace Pin 233 in one of the two holes in Swivel, 231-B, which is nearest in alignment with hole in Nut, 232.

Crucible Compression Adjustment

To maintain the proper lock-up between the mouthpiece and the under side of the mold, the following adjustments must be carefully checked:

With the table top raised, operate the machine by hand until the mouthpiece is pressing firmly against the under side of the mold, which is in its highest position. At this point the Castellated Nut, 214-A, should be in such position that it is raised $\frac{1}{16}$ inch above its seat, as shown at "C". This insures the proper pressure of the mouthpiece against the under side of the mold. This adjustment may be changed by removing the Cotter Pin, 219, and turning the Castellated Nut, 214-A, up or down until the proper location is reached, after which replace the cotter pin.

Centering Mouthpiece Opening With Mold

With the table top raised, operate the machine by hand until the mouthpiece has swung into position under, and is in compression with the mold. At this point the mouthpiece orifice should be exactly centered in the mold opening, and if not in the center, adjustment may be made as follows:

Swing up the Crucible Adjusting Bolt Guard, A213A, and loosen the two Clamp Screws, 59, and the two Check Nuts,

235. Then unscrew one Adjusting Screw, 229 $\frac{1}{2}$, and screw in the other adjusting screw to give the desired location. For instance, if it is necessary to move the crucible to the left, unscrew the left-hand screw, screw in the right-hand screw the desired amount, after which tighten the left-hand screw until it bears against the Crucible Cam Lever, 234B. Then tighten the Check Nut, 234, and the Screws, 230, and lower the Guard, A235A.

Plunger Weight Adjustment

The plunger should be so adjusted that its bottom edge is $\frac{1}{16}$ inch above the lower edge of the port in the wall. This adjustment may be checked by removing the Cotter Pin, 68, and Pin, 275. This will permit the plunger to float in the wall. A piece of wire $\frac{1}{4}$ inch in diameter should be bent into an "L" shape, so that one end may be inserted through the molten metal into the porthole of the wall of the crucible. After the wire has been inserted through the porthole, the plunger should be pressed down upon the wire. With the plunger in this position, the hole in the Plunger Connecting Lever, 274A, should line up with the hole in the Connecting Rod, 271A. If these holes are not in alignment, loosen Check Nut, 59, at the bottom of the Connecting Rod, 271A, and turn the connecting rod up or down as required. After adjustment is completed, tighten Check Nut, 59, and replace all parts. Any variation from the correct setting of the plunger will result in hollow slugs, unsatisfactory face, or both.

Plunger Spring Adjustment

At the time of installation the plunger spring pressure should be rechecked. Using the largest point size matrix in the area plant with the plunger hand lever in the bottom position, adjust the tension of the plunger springs so there is a slight sign of resistance on the under side of the T-head of the slug. Then release the plunger springs until the "bulge" disappears. Care should be taken that each plunger spring is

rotated an equal amount when this adjustment is made. Because the "lifting action" of the molten metal between the mold and matrices is greater on the larger point sizes, it is possible to use additional plunger spring pressure with the smaller point size typeface matrices as well as with rubiform matrices.

Table Latch Adjustment

The adjustment of the Table Latch, 98B, by means of which the table top is locked to the frame of the machine during the casting operation, should be made when the machine is in its idle position.

The Spring, 73S, attached to that part of the table latch which is under the table top, should be removed and the table top should be lowered and locked down with the front Table Catches, A33A and 60. That part of the adjustable lock which projects through the top of the table may then be grasped and moved back and forth. If it moves very freely, the pawl should be raised, after loosening screws, and the notched eccentric bushing moved to the left by turning the bush one notch at a time until the latch binds slightly when it is moved back and forth. The pawl should then be dropped into position and the screw which holds it in place tightened and the spring underneath the table replaced. If it is not possible to get the proper adjustment through the turning of the eccentric bushing, further adjustment may be made by raising or lowering that part of the Latch, 98B, which is attached to the main frame. To make this adjustment, the check nut should be loosened, which will allow the screw to be turned, thus raising or lowering Latch, 98B. The check nut should then be locked and the final close adjustment made with the eccentric bushing, as stated above.

During the casting part of the cycle, the automatic lock is in operation, locking the table down to the main frame of the machine. This lock is actuated by a Screw Stud, 77, which is fastened to the main slide by a bracket held in place with two

across. When the slide rises, this stud striking the diagonal side of the latch pushes it into position underneath the pin in the Latch, 91B. This stud is purposely made so that it will break in case there is some obstruction to the operation of the latch, protecting the more delicate parts of the locking mechanism. In the event the stud breaks off, the cause should be located and corrected and the stud replaced. Operate machine slowly by hand to see if the latch functions properly before turning on the motor.

When Machine Stalls in Casting Position

In the event the machine should stall due to a hot metal flash (just as the cast is being made, or has just been made), it will be necessary to raise the Table, No. 4L, to investigate and correct the trouble, but before attempting to raise the table, the following procedure is imperative:

1. "Throw" the motor switch to the "off" position.
2. Remove Plunger Connecting Lever Pin, 275.
3. Remove the Safety Lever Screw, 730 $\frac{1}{2}$, which connects the Safety Connecting Rod, 747B. These parts are located on top of the table.
4. This should permit the plunger cam lever to be depressed enough so that the Safety Finger, 753A, may be positioned over the top of the projecting end of the plunger cam lever. It is most important that the safety finger be positioned over the cam lever before any attempt is made to raise the table.
5. Release the Rear Table Latch, 868, by removing the threaded Table Latch Yoke Pin, 83A. The removal of this threaded pin is accomplished by inserting a long screw driver through the $\frac{1}{2}$ inch hole located on the rear side of the table near the center, and unscrewing the threaded pin, thereby releasing Table Latch, 868.
6. Release the front Table Catcher, 893A and 97. The table may now be raised for observation of the location of the metal flashings.

7. Remove all metal flashings from the movable parts as well as the interior of the machine generally.

8. Add new Safety Key, 153B.

9. Replace Plunger Connecting Lever Pin, 275.

10. Reassemble all parts which have been removed.

11. Operate the machine manually until the cast slab returns to the neutral or tilting position.

Ejector Blade

If the Ejector Blade, A659A, is removed for any reason, clean the shoulder upon which it rests very thoroughly before it is replaced, as any dirt or metal on this shoulder will tip the ejector and cause a drag on the ribs of the slag. The top surface of the ejector must be parallel with the mold.

Delivery Slide

To adjust the Slag Holders, A663H and A664H, remove the slide from the machine by removing the Manulpiece Wiper Bracket, A886K, which also retains the left side of the slide, and the Slag Carrier Operating Block, A695A, which retains the right side of the slide. Turn the slide bottom side up, first making sure the Slag Holder Operating Plates, 645B, are not bent, then take two pieces of straight metal, such as 12-pt. slugs, and hold them firmly against the slides of the delivery slide casting so that they depress the Slag Holder Cams, A446A and A446 $\frac{1}{2}$ A. The slag holders should then be in a vertical position. If they are not in this position, loosen the Set Screws, 578, and turn the Adjusting Screws, 658 $\frac{1}{2}$, until the proper adjustment is obtained, after which tighten the Set Screws, 578.

Adjust the two Screws, 668, in the Slag Holder Bearing Plate, 671C, so that the distance between slag holders, when closed, is approximately 13 points. Also, the two shoulders on the slag holders, on which the slag rests, should be of the same height and on the center line of the opening in the delivery slide. Place the slide back in the machine. Replace parts A886K and A695A.

Metal Mold Wiper

After the machine has been in service for some time, the lower edge of the Metal Mold Wiper, 656D, may become rounded off to such an extent that the mold will not be wiped clean. To replace mold wiper, turn it one-quarter turn and remove it from under the head of the stud. Place new wiper under the head of the stud and turn mold wiper scrape into place.

To adjust the Mold Wiper Arm, A678½B, operate the machine by hand until the mold has reached the highest point of its travel, at which point it should be possible to raise the mold wiper arm about two points. If this adjustment is not correct, loosen Check Nut, 230, located under mold wiper arm near its fulcrum, after which Adjusting Screw, 701, may be turned until the proper adjustment is obtained. Then tighten nut.

To adjust the mold wiper arm rest, operate the machine by hand until the delivery slide has reached the farthest point of its travel toward the rear of the machine and has started back to the front of the machine for a distance of 1 or 2 inches.

Loosen Check Nut, 230. Place a sheet piece of 2-pt. lead between Adjusting Screw, 696½, and Mold Wiper Arm, A678½B, and adjust the screw so it just bears against the 2-pt. lead. Then tighten the Check Nut, 230.

To adjust the Mold Wiper Arm Cam, 691½A, proceed as follows:

Operate the machine by hand until the delivery slide has reached the farthest point of its travel toward the rear of the machine, at which point Cam, 691½A, should have just been tripped by contact of the Screw, 980A, against the lug on the Mouthpiece Wiper Bracket, A308K. Any necessary adjustment may be made by loosening Nut, 225, and turning Adjustment Screw, 980A, until the proper adjustment is obtained. Operate the machine slowly by hand before applying the power.

Gas-Heated Crucible

To obtain best results with a gas-heated crucible, be sure that the supply line is large enough so there will be no drop in gas pressure if the burners are turned on suddenly to their maximum capacity. Whenever possible, the Ludlow crucible should be connected to a supply line that has a pressure regulator.

There are two burners in the gas crucible: a Mouthpiece Burner (which is located under the front and mouthpiece) and the Main or Base Burner directly under the crucible.

The gas thermostat on the Ludlow crucible should, when it is properly set, maintain the temperature of the metal in the crucible from 550° to 665° F.

In some localities, the quality of the gas is such that after burners have been in use for some time they may become clogged. If air pressure is available near the machine, it is a good plan to blow out the burners and mixing valves every few weeks. Bellows may also be used for this purpose.

Do not place the machine in such a position that it will be subjected to severe drafts of air, as this will cause sudden variation of temperature in the crucible, due to the blowing of the flames.

Electric-Heated Crucible

The Ludlow Electric Crucible is so constructed and wired that the terminals, switches, circuit breakers, etc. are readily accessible.

All terminals and wires are plainly marked and correspond to the markings as shown in the wiring diagram.

The main feed wires enter the bottom of the control panel and are connected to the terminals as shown.

From the main hand switch, the wiring is divided into four circuits, as follows:

- Crucible Heater Circuit
- Thermostat Circuit

Throat and Mouth Heater Circuit Motor Circuit

These circuits are illustrated in separate colors on the wiring diagram for convenient tracing.

Machine Must Be Grounded

All tests are based on the supposition that the machine is grounded. In most cases the machine is grounded by the line wire conduit. In case an adequate ground is not so established, it will be necessary to connect a No. 10 wire between the frame of the machine and a water pipe, or some other safe means of transmission to the ground.

Test Lamp

A Test Lamp, ARS2A, may be used for locating most electrical trouble in the crucible.



Test Lamp, ARS2A

How to Use Test Lamp

The test lamp may be used to locate a "ground," an "open circuit," or a "dead" heating element. An explanation of terms follows:

Open Circuit

An incomplete circuit, one broken at any point, so that current does not flow through any part of it. A broken wire or loose connection can cause an open circuit.

Dead Heater

A heater that has an open circuit.

Ground

An electrical connection between an electrical circuit and the crucible or frame of the machine.

Short Circuit

A connection between the two sides of a circuit so that the current takes a shorter path than is intended.

Preliminary Tracing of Electrical Trouble

All circuits are protected by circuit breakers. In case of ground or short, circuit breaker goes automatically to "off" position. When possible is corrected, switch circuit breaker to "on" position. Other indications of electrical trouble will be variations of temperature of the type metal in the crucible or at the mouthpiece, or stopping of machine. Variations of temperature have to do with the crucible, throat or mouth-piece heaters or circuits. Stopping of the motor is confined to the motor circuit.

Control Panel Test

With test lamp short-circuited, place test points on power terminals. If the current reaches these terminals, the lamp will light. If the lamp does not light, test the main output lines.

Open Circuit Test

Turn on the panel hand switch and, with test lamp short-circuited, make the same test on terminals of each circuit. This test should light the lamp.

If the above tests fail to light the lamp, the failure may be due to a broken wire, loose connection, a defective hand switch or a faulty unit, which must be corrected.

Ground Test

With the panel switch turned off, remove the lead wires from all terminals and with the test lamp connected to a lighting circuit touch each of the terminals in the control panel with the live point of the test lamp. If a light shows, it indicates a ground which must be corrected.

Short Circuit Test

If the metal in the crucible fails to melt out, or if the mouthpiece freezes and there is no indication of either an open circuit or a ground, check the circuit breakers. If in "on" position, turn to "off" position and check the wires as well as each of the heating units for a short circuit. The test lamp described above cannot be used successfully for all short circuit tests. An ordinary light bulb test should be made on the terminals of the heating units. A dim light indicates there is no short circuit. A bright light indicates a short circuit.

Motor Circuit Test

If the motor fails to start, slows down, stops, or overloads, it is an indication of trouble in the motor or motor circuit. Before making any tests, remove the belt and see if the trouble persists. If motor runs satisfactorily with the belt removed, then look for mechanical trouble in the machine. If motor fails to operate with belt removed, check motor circuit as outlined above.

Crucible Thermometer Adjustment

Insert hot metal thermometer near the mercury bulb in the crucible metal and allow sufficient time for the thermometer reading to reach the temperature of the metal. Open back of thermostat. Loosen set screw and turn "stem" with wrench supplied with thermostat until the indicating hand corresponds with the temperature shown by the thermometer and then tighten the set screw.

Mouthpiece Thermometer Adjustment

To calibrate the mouthpiece thermometer:

Set crucible temperature 550°.


Turn off current for the mouthpiece and throat units at circuit breaker.

Heat from the crucible will also heat the throat and mouthpiece. Allow 30 minutes for heat to equalize. There will be some heat lost, so that when the temperature of the metal in the crucible is 550° the temperature at the bulb of the mouthpiece thermometer will be approximately 450°.

If the mouthpiece thermometer does not read 450°, then loosen set screw and turn stem until the indicating hand is at 450° and tighten set screw. Turn on current at circuit breaker.

This method of calibrating the mouthpiece thermometer will result in metal temperatures within 10° plus or minus. A more accurate adjustment is possible by using a surface thermometer at the mouthpiece, although this is not regarded as essential, since the heat at the mouthpiece and throat of crucible will depend upon local conditions.

Plate No. 1




FRONT VIEW

END VIEW

(S1238-(1425 RPM))
(S1248-(1725 RPM))

Machine Drive Parts - Plate No. 2

Part No.	Description	Part No.	Description
15A	Oil	159	Driving Clutch Gear Hub
A16	Main Shaft Assembly (Sold only as an assembly —includes 22½)	160C	Motor Base
21	Main Shaft Collar—Right	160D½	Motor Base Washer
22½	No. 4 Taper Pin—2½" long	163C	Driving Clutch Shaft
26	Main Shaft Bearing—Right	168	¾" x 18 x 1½" long Hexagon Head Cap Screw
28	Main Shaft Bearing Cap—Right	171	¼" x 20 x ¾" long Flat Fillet Head Screw
37A	Leg (Right)	180A	Drive Shaft Bracket
A48A	Table Assembly (Sold only as an assembly)	181	¾" x 14 x 1½" long Hexagon Socket Cap Screw
64	¼" lock size 1½" OD x ¾" thick Washer	182	¾" dia. x 1½" long Hardened Dowel Pin
92	¾" x 18 Hexagon Nut	197	Clutch Shaft Oil Tube
A100A	Motor—¼ hp (Specify rpm, voltage, cycles and phase)	198	Clutch Body Oil Tube
118A	Motor Shim—for 1425 rpm motor only (not illustrated)	199	Pulley Shaft Oil Tube
A120B	Motor Pulley and screw—¼" bore— for 1425 rpm motor	82219	¾" x 18 x ¾" long Hexagon Head Cap Screw
A124B	Motor Pulley and screw—¼" bore— for 1725 rpm motor	405A	Tripping Lever
A136D	Pulley	406	Tripping Lever Stud
136½	Pulley Key	407	Tripping Lever Connection
A137C	Pulley Shaft Assembly (includes 138L, 140A and 140½)	408	Tripping Lever Connection Stud
139D	Pulley Pinion (sold only in A137C)	410	Tripping Lever Intermediate
140A	¾" dia. x 1½" long Roll Pin	415A	Tripping Lever Intermediate Bracket
140½	Pulley Pinion Hub	419½	No. 10-32 x 1" long Hexagon Socket Cap Screw
142B	Main Drive Belt	420	Tripping Lever Clinch
A150	Main Shaft Driving Gear Assembly (Includes 450A, 451 and 452½)	423	Clutch Body
150½C	Motor Wiring Outlet Bracket	425	Clutch Body Oil Tube Bushing
151A	Driving Gear Pinion	434A	Clutch Release
A155A	Driving Clutch Gear Safety Knut Screws	435A	Clutch Release Fulcrum
155½A	Driving Clutch Gear Safety Knut Screws	A436B	Clutch Release Yoke Assembly
156A	Driving Clutch Gear	437	Clutch Release Connection
158	Driving Clutch Gear Safety Key	A452C	Clutch Release Bracket Assembly
		450A	Clutch Disc
		460	¾" x 18 x 1½" long Cap Point Hexagon Socket Self Locking Set Screw
		584	¾" Bolt Size x 1½" OD x ¾" thick washer
		1198½	½" x 23 x 1½" long Hexagon Head Cap Screw
		1430A	¾" x 20 Heavy Hexagon Nut
		1650	¾" x 20 x 1" long Hexagon Head Cap Screw



Clutch Mechanism - Plate No. 2

Part No.	Description	Part No.	Description
16	Main Shaft (sold only as assembly A-16)	430	$\frac{1}{16}$ " dia. x $\frac{1}{16}$ " long Dowel Pin
21	Main Shaft Collar—Right	431	Clutch Release Yoke Spring
25 $\frac{1}{2}$	No. 6 Taper Pin—2 $\frac{1}{2}$ " long	434A	Clutch Release
28	Main Shaft Bearing Cap—Right	435A	Clutch Release Fulcrum
68	$\frac{1}{16}$ " dia. x $\frac{1}{16}$ " long Center Pin	44000	Clutch Release Yoke and Extension Assembly
95	$\frac{1}{4}$ "-18 Hexagon Nut	437	Clutch Release Connection
158	Driving Gear—Main Shaft	438	Clutch Release Yoke Spring Plunger
153A	Driving Gear Plates	438 $\frac{1}{2}$	$\frac{1}{16}$ "-20 x $\frac{1}{16}$ " long Oval Point Slotted Headless Set Screw
160C	Driving Clutch Shaft	442C	Clutch Release Bracket
171	$\frac{1}{4}$ "-20 x $\frac{1}{16}$ " long Flat Filler Head Screw	444	Clutch Release Spring Plunger
188A	Drive Shaft Bracket	445A	Clutch Release Spring
189	$\frac{1}{16}$ " Dia. x 1 $\frac{1}{4}$ " long Hardened Dowel Pin	446	$\frac{1}{16}$ "-18 x $\frac{1}{16}$ " long Cap Point Slotted Headless Set Screw
M200	$\frac{1}{4}$ "-18 x $\frac{1}{16}$ " long Oval Point Slotted Headless Set Screw	450A	Clutch Disc
239	$\frac{1}{4}$ "-20 Standard Jam Nut	451	$\frac{1}{8}$ "-20 x $\frac{1}{16}$ " long Flat Head Hexagon Socket Cap Screw
408	Tripping Lever Connection Stud	452 $\frac{1}{2}$	$\frac{1}{16}$ " dia. x $\frac{1}{16}$ " long Roll Pin
418	Tripping Lever Clevis	457	$\frac{1}{16}$ "-24 x $\frac{1}{16}$ " long Cap Point Hexagon Socket Headless Set Screw
419	No. 10-30 x $\frac{1}{16}$ " thick Jam Nut	584	$\frac{1}{16}$ " Bolt Size x $\frac{1}{16}$ " OD x $\frac{1}{16}$ " thick Washer
423	Clutch Body	701	$\frac{1}{16}$ "-20 x 1" long Oval Point Slotted Headless Set Screw
425	$\frac{1}{16}$ " dia. x $\frac{1}{16}$ " long Dowel Pin	1462 $\frac{1}{2}$	No. 13 Woodruff Key
426	Clutch Pin		
427	Clutch Pin Spring		
429	No. 8-32 x $\frac{1}{16}$ " long Round Head Screw with lock washer		

Plate No. 3




TABLE LIFTER

Table Lifter - Plate No. 2

Part No.	Description	Part No.	Description
10B	Main Frame (not sold)	57½	Table Lifter Handle
11B	Frame Front Plate	58B	Table Lifter Fulcrum
16	Main Shaft (sold only as assembly A-34)	59½	½"-18 Hexagon Steel Cap Nut
17	Main Shaft Bearing—Left	60	Table Lifter Latch
18	½"-20 x ½" long Flat Filler Head Screw	66	Table Lifter Link
19	Main Shaft Bearing Cap—Left	67	Table Lifter Link Hinge Pin
20	½"-18 x 2" long Hexagon Socket Cap Screw	68	¾" dia. x ¾" long Center Pin
20½	No. 8 Taper Pin—2½" long	69	Table Lifter Link Slide Pin
23	Main Shaft Collar—Left	72	Table Lifter Slide
30A	Frame Cover	75	Table Lifter Slide Cap
38	½"-18 x 1½" long Hexagon Head Cap Screw	80A	Table Guard—Left Hand
36A	Log	84A	Table Guard—Left Hand Base
44	½" Bolt Size x 1" OD x ¼" thick Washer	171	½"-20 x ¾" long Flat Filler Head Screw
48A	Table (sold only as assembly A-45-A)	M125	½"-20 x ¾" long Round Head Screw
49	Table Hinge	M216	½" Bolt Size x 7½" OD x ¼" to ⅜" thick Steel Washer
50	½" Dia. x 2" long Dowel Pin	405	Table Lifter Latch Fulcrum
51	½"-20 x ¾" long Cap Point Slotted Headless Set Screw	511	¾"-18 x ¾" long Flat Filler Head Screw
52	Table Hinge Bracket	632	No. 10-30 x ¾" long Round Head Screw
52½	½"-18 x 1" long Hexagon Head Cap Screw	738A	¾" dia. x 7½" long Ball Pin
53½	No. 10-30 x ¾" long Truss Head Machine Screw	908B	Galley Base
54	½" Dia. x ¾" long Hardened Dowel Pin	908A	Galley Bracket
55A	Table Lifter		

Table Top Assembly - Plate No. 4

Part No.	Description	Part No.	Description
18	$\frac{1}{4}$ " \times 20 x $\frac{1}{2}$ " long Flat Filler Head Screw	521A	Locking Release Rod Yoke
43	$\frac{3}{16}$ " dia. x $\frac{1}{2}$ " long Dowel Pin	525A	Locking Release Positive Clutch Knob
44	$\frac{3}{16}$ " dia. x $\frac{1}{2}$ " long Dowel Pin	535	Locking Release Tripper Holder
47	Table Latch Spring Stud	534	Locking Slide Safety Bumper Filtrum Screw
48A	Table (sold only as assembly A-48A)	540C	Locking Slide Safety Pawl Bumper (21 mm—Use 555C for 25 $\frac{1}{2}$ mm)
49	Table Hinge		
50	$\frac{1}{2}$ " dia. x 2" long Dowel Pin	545A	Locking Lever Body
51	$\frac{1}{4}$ " \times 20 x $\frac{1}{4}$ " long Cup Point Slotted Headless Set Screw	545 $\frac{1}{2}$	Locking Lever Arm
		547	Locking Lever Handle
52	Table Hinge Bracket	548	Locking Lever Handle Screw
53A	Table Filling Piece	555A	Locking Lever Anchor
53 $\frac{1}{2}$	No. 18-30 x $\frac{1}{4}$ " long Trans Head Machine Screw	559B	Locking Lever Link
61A	Table Filling Piece Opening Cover	563A	Locking Equalizing Bar Clamp Adjusting Screw
70A	Table Latch Eccentric Bushing	566C	Locking Slide
70 $\frac{1}{2}$	Table Latch Eccentric Bushing Stop	570	No. 8-36 x $\frac{1}{2}$ " long Filler Head Screw
71A	Table Latch Pawl	571	Locking Slide Guide—Front
78	Table Guard—Right Hand	575	No. 8-36 x $\frac{1}{4}$ " long Oval Point Slotted Headless Set Screw
80A	Table Guard—Left Hand		
82	Table Guard—Right Hand Rear	574C	Locking Slide Guide—Rear
84A	Table Guard—Left Hand Rear	575B	Locking Guide
85A	Table Latch Bracket	576A	Locking Guide Screw
88B	Table Latch	577B	Locking Slide Guide Screw—Rear
87A	Table Latch Shaft	578C	Stick Stop Slide and Locking Adjusting Block Guide
87 $\frac{1}{2}$	No. 18-30 x $\frac{1}{4}$ " long Oval Point Slotted Headless Set Screw	578 $\frac{1}{2}$	$\frac{3}{16}$ " \times 18 x $\frac{1}{4}$ " long Flat Filler Head Screw
90 $\frac{1}{2}$	Table Latch Pawl Stud	579B	Locking Slide Safety Pawl—Rear
94B	No. 18-30 x $\frac{1}{4}$ " long Flat Filler Head Screw	579 $\frac{1}{2}$	$\frac{3}{16}$ " \times 18 x 1 $\frac{1}{4}$ " long Flat Filler Head Screw
526	$\frac{3}{16}$ " dia. x $\frac{1}{2}$ " long Dowel Pin	581	$\frac{1}{2}$ " dia. x $\frac{1}{2}$ " long Dowel Pin
512	$\frac{3}{16}$ " dia. x $\frac{1}{2}$ " long Dowel Pin	582B	Stick Stop Slide and Locking Adjusting Block Guide Adjusting Screw
519	Locking Release Catch		
518A	Locking Release Bell Crank	585A	Locking Equalizing Lever
520A	Locking Release Rod	586A	Locking Equalizing Lever Stud

Table Top Assembly - Plate No. 4


Part No.	Description	Part No.	Description
502A	Locking Equalizing Bar Clamp	A733A	Safety Lever Shaft Bearing Assembly
506C	Locking Equalizing Bar	738B	Safety Operating Lever
501	Locking Equalizing Bar Stud	740A	Safety Operating Lever Fulcrum
503 1/2	Locking Equalizing Lever Adjusting Screw Cap	747B	Safety Connecting Rod
504	Locking Equalizing Bar Shoe	555	Safety Finger Spring—Upper
506	Locking Equalizing Bar Clamp Roller	757	1/4"-20 x 1/4" long Button Head Socket Screw
507A	Locking Equalizing Bar Clamp Roller Fulcrum	768	Lock Down Knob
608	1/4"-20 x 1/4" long Flat Filister Head Screw	918A	Slag Pusher Cam Stud
T247 1/2 A	Stick Stop Slide Pin	944 1/2	No. 8-36 x 3/16" long Truss Head Screw
738A	Safety Lever		

Table Top Parts - Plate No. 5

Part No.	Description	Part No.	Description
83	$\frac{1}{8}$ "-20 x $\frac{1}{2}$ " long Flat Fillister Head Screw	546A	Locking Lever Body
48A	Table (sold only as assembly A-48-A)	546½	Locking Lever Arm
70A	Table Latch Eccentric Bushing	547	Locking Lever Handle
85A	Table Latch Bracket	548	Locking Lever Handle Screw
86B	Table Latch	550	Locking Lever Fulcrum
87A	Table Latch Shaft	552A	Locking Lever Anchor
811B	$\frac{1}{8}$ "-20 x $\frac{1}{2}$ " long Round Head Screw	556	Locking Lever Anchor Screw
5207	$\frac{3}{16}$ " dia. x $\frac{1}{2}$ " long Dowel Pin	557	$\frac{3}{16}$ " dia. x $\frac{1}{2}$ " long Hardened Dowel Pin
520	$\frac{1}{8}$ "-20 x $\frac{3}{16}$ " thick Jam Nut	558B	Locking Lever Link
528	No. 10-32 x $\frac{1}{2}$ " long Flat Fillister Head Screw	560	Locking Lever Link Stud
528	$\frac{3}{16}$ " dia. x $\frac{1}{2}$ " long Dowel Pin	561	Locking Lever Spring
519	No. 10-32 x $\frac{1}{2}$ " thick Jam Nut	563A	Locking Equalizing Bar Clamp Adjusting Screw
512	$\frac{3}{16}$ " dia. x $\frac{1}{2}$ " long Dowel Pin	1066C	Locking Slide
516	Locking Release Catch	567	Locking Slide Shoe
517	$\frac{1}{8}$ " dia. x $\frac{3}{16}$ " long Dowel Pin	568	Locking Slide Shoe Spring
518A	Locking Release Bell Crank	569	No. 8-36 x $\frac{1}{2}$ " long Flat Fillister Head Screw
520A	Locking Release Rod	570	No. 8-36 x $\frac{1}{2}$ " long Flat Fillister Head Screw
521A	Locking Release Rod Yoke	571	Locking Slide Guide—Front
522	$\frac{1}{8}$ " dia. x $\frac{3}{16}$ " long Dowel Pin	573	No. 8-36 x $\frac{3}{16}$ " long Oval Point Slotted Headless Set Screw
523B	Locking Release Rod Spring	574C	Locking Slide Guide—Rear
524A	Locking Release Position Catch Sleeve	81573B	Locking Guide
525A	Locking Release Position Catch Knob	578A	Locking Guide Screw
525½	Locking Release Position Catch Pin	577B	Locking Slide Guide Screw—Rear
526½	Locking Release Position Catch Spring	578½	$\frac{3}{16}$ "-18 x $\frac{1}{2}$ " long Flat Fillister Head Screw
525	Locking Release Trigger Holder	579B	Locking Slide Safety Pad—Rear
534	Locking Slide Safety Pawl Bumper Fulcrum Screw	579½	$\frac{3}{16}$ "-18 x 1½" long Flat Fillister Head Screw
540C	Locking Slide Safety Pawl Bumper (21 mm—Use 996C for 22½ mm)	580	Locking Slide Safety Pawl Spring
541	Locking Slide Safety Pawl Bumper Stop Pin	581	$\frac{1}{8}$ " dia. x $\frac{1}{2}$ " long Hardened Dowel Pin
543	Locking Slide Safety Pawl	582B	Stick Stop Slide and Locking Adjusting Block Guide Adjusting Screw
544	Locking Slide Safety Spring	584	Locking Guide Screw Washer
545	Locking Slide Safety Pawl Manger		

Table Top Parts - Plate No. 5

Part No.	Description	Part No.	Description
505A	Locking Equalizing Lever	714	Stick Stop Adjusting Screw
505A	Locking Equalizing Lever Stud	715	Stick Stop Spring
507	Locking Equalizing Lever Spring	722	Stick Stop Slide Bumper Block
508A	Locking Equalizing Bar Clamp	724 $\frac{1}{2}$	Stick Stop Slide Knob
509 $\frac{1}{2}$	Locking Equalizing Bar Clamp Spring	725B	Stick Stop Slide
509	Locking Equalizing Bar Lock Washer	726	Stick Stop Slide Spring
509C	Locking Equalizing Bar	730A	Safety Lever
501	Locking Equalizing Bar Stud	730 $\frac{1}{2}$	Safety Lever Screw
502	Locking Equalizing Bar Stop Pin	731	No. 2 x 1" long Taper Pin
503	Locking Equalizing Lever Adjusting Screw	732A	Safety Lever Shaft
503 $\frac{1}{2}$	Locking Equalizing Lever Adjusting Screw Cap	A.130A	Safety Lever Shaft Bearing Assembly
504	Locking Equalizing Bar Shoe	734	$\frac{1}{4}$ "-20 x $\frac{1}{2}$ " long Round Head Screw
506	Locking Equalizing Bar Clamp Roller	739B	Safety Operating Lever
507A	Locking Equalizing Bar Clamp Roller Fulcrum	740A	Safety Operating Lever Fulcrum
507 $\frac{1}{2}$ A	Locking Equalizing Bar Clamp Roller Fulcrum Screw	747B	Safety Connecting Rod
508	Locking Slide Safety Panel Fulcrum	754	$\frac{3}{16}$ " dia. x $\frac{1}{2}$ " long Hardened Dished Pin
509	Locking Equalizing Bar Screw Rest	767	$\frac{1}{4}$ "-20 x $\frac{3}{4}$ " long Hexagon Socket Button Head Screw
600	$\frac{1}{4}$ "-20 x $\frac{1}{2}$ " long Flat Filister Head Screw	768	Lock Down Knob
709	Stick Stop (21 mm—use 712 for 22 $\frac{1}{2}$ mm)	769	Lock Down Knob Washer
712A	Stick Stop Adjusting Screw Set Screw	918A	Slag Pusher Cam Stud




Delivery Slide Assembly - Plate No. 8

Part No.	Description	Part No.	Description
135	No. 10-30 x $\frac{1}{2}$ " long Round Head Screw	655 $\frac{1}{2}$ C	Delivery Arm Bracket Guard Cover
171	$\frac{1}{4}$ "-20 x $\frac{3}{16}$ " long Flat Filler Head Screw	657 $\frac{1}{2}$ A	Delivery Arm Shock Pad (Leather)
216	No. 8-36 x $\frac{1}{2}$ " long Round Head Screw	658 $\frac{1}{2}$	Delivery Arm Bushing
230	$\frac{1}{4}$ "-20 Standard Jam Nut	659	Delivery Arm Pulverizer
248	No. 10-30 x $\frac{1}{2}$ " long Flat Filler Head Screw	660B	Slag Guide—Right Hand
325	No. 8-36 Hexagon Nut	A661A	Delivery Arm Cam Assembly
415	10-36 Shoulder Screw (Same as Table Lifter Latch Pulverizer)	661A	Delivery Arm Cam
419	No. 10-30 Standard Jam Nut	661 $\frac{1}{2}$ A	Delivery Arm Cam Stud
425	$\frac{1}{8}$ " Dia. x $\frac{1}{2}$ " long Dowel Pin	662B	Slag Guide—Left Hand
529	$\frac{3}{8}$ " OD x $2\frac{1}{2}$ " Overall Length Extension Spring	662 $\frac{1}{2}$	Delivery Arm Cam Spring
550	No. 8-36 x $\frac{3}{8}$ " long Filler Head Machine Screw	A663H	Slag Holder Assembly—Right Hand
573	No. 8-36 x $\frac{1}{2}$ " long Oval Point Slotted Headless Set Screw	663B	Slag Holder—Right Hand
622 $\frac{1}{2}$	$\frac{1}{8}$ " Dia. x $2\frac{1}{2}$ " long Dowel Pin	(sold only as assembly A-663-H)	
636	Slag Holder Cam Stud	663 $\frac{1}{2}$	Delivery Arm Cam Spring Stud—Long Shoulder
636 $\frac{1}{2}$	No. 8-36 x $\frac{1}{2}$ " long Oval Point Slotted Headless Set Screw	A664H	Slag Holder Assembly—Left Hand
643B	Slag Holder Operating Plate	664B	Slag Holder—Left Hand
643 $\frac{1}{2}$	Slag Holder Operating Plate Rivet	(sold only as assembly A-664-H)	
A665A	Slag Holder Cam Assembly (Right Hand)	664 $\frac{1}{2}$	Delivery Arm Cam Spring Stud—Short Shoulder
A665 $\frac{1}{2}$ A	Slag Holder Cam Assembly (Left Hand)	665C	Slag Holder Spring
A666B	Delivery Slide Assembly	667 $\frac{1}{2}$	Slag Holder Spring Stud
650	Delivery Slide	668A	Slag Holder Stop Pin
651 $\frac{1}{2}$	Hold Wiper Arm—Front	668 $\frac{1}{2}$ A	Mold Wiper Arm Extension
652 $\frac{1}{2}$	Delivery Slide Controlling Pin	669	Slag Holder Equalizing Screw
654 $\frac{1}{2}$	$\frac{1}{8}$ " Dia. x $\frac{3}{16}$ " long Dowel Pin	670H	Slag Holder Bearing Plate—Rear
A655B	Delivery Arm Assembly	670 $\frac{1}{2}$	Slag Holder Bearing Pin
A655B-1	Delivery Arm Sub-Assembly	671C	Slag Holder Bearing Plate—Front
665D	Delivery Arm (sold only as assembly A-655-D)	672 $\frac{1}{2}$	Slag Support Fish Stud
665 $\frac{1}{2}$	Delivery Arm Bracket Guard	673	Delivery Arm Cam Operating Stud
		674C	Delivery Slide Cover
		674 $\frac{1}{2}$ A	Mold Wiper Arm Cam Rest
		675	Delivery Arm Cam Rest
		2, 675 $\frac{1}{2}$	Delivery Arm Spring

Delivery Slide Assembly - Plate No. 8

Part No.	Description	Part No.	Description
676D	Mold Wiper	6981 $\frac{1}{2}$	Mold Wiper Arm Cam Spring Stud
6781 $\frac{1}{2}$	$\frac{1}{8}$ " Dia. x $\frac{1}{4}$ " long Dowel Pin	A6811 $\frac{1}{2}$ A	Mold Wiper Arm Cam Assembly
A6701 $\frac{1}{2}$ B	Mold Wiper Arm Assembly	6991 $\frac{1}{2}$ A	Mold Wiper Arm Cam
6781 $\frac{1}{2}$ R	Mold Wiper Arm—Rear	699F	Slag Puller
678B	Delivery Arm and Mold Wiper Arm Guide	6991 $\frac{1}{2}$ B	Slag Puller Bracket
6791 $\frac{1}{2}$	Delivery Arm Spring Plunger	A688F	Slag Carrier Assembly
681 $\frac{1}{2}$	$\frac{1}{4}$ "-20 x $\frac{1}{2}$ " long Cap Point Hexagon Socket Set Screw	699F	Slag Carrier Back
6821 $\frac{1}{2}$	Mold Wiper Arm Fulcrum	6991 $\frac{1}{2}$	Slag Puller Spring
A683D	Slag Support Assembly	6941 $\frac{1}{2}$	Slag Puller Hinge Pin
683D	Slag Support	6991 $\frac{1}{2}$ A	Mold Wiper Arm Cam Fulcrum
6831 $\frac{1}{2}$ B	Slag Support Fulcrum	696A	Delivery Slide Pin
684A	Slag Support Felt	6961 $\frac{1}{2}$	Mold Wiper Arm Rest Screw
6841 $\frac{1}{2}$ A	No. 8 x $\frac{1}{4}$ " OD Washer	697	Delivery Slide Operating Rack Stop Pin
685A	Slag Carrier Gear—Upper	6971 $\frac{1}{2}$	Mold Wiper Arm Cam Return Spring Stud
6851 $\frac{1}{2}$	No. 3-44 x $1\frac{1}{4}$ " long Oval Point Slotted Headless Set Screw	A699	Slag Carrier Gear Assembly, consisting of parts, 685A, 688, 687, 689 and 6891 $\frac{1}{2}$ (Not Illustrated)
686	Slag Carrier Gear—Lower	6991 $\frac{1}{2}$ A	Mold Wiper Lock Stud
687	Slag Carrier Gear Spring Washer	701	$\frac{1}{4}$ "-20 x 1" long Oval Point Slotted Headless Set Screw
6871 $\frac{1}{2}$	Mold Wiper Arm Plunger	704	Mold Wiper Stop Pin
688	Slag Carrier Gear Clamp Washer	714	Delivery Slide Pin Screw
6881 $\frac{1}{2}$	Mold Wiper Arm Plunger Spring	699	Slag Pusher Cam Ball
6891 $\frac{1}{2}$	$\frac{1}{8}$ " Dia. x $\frac{1}{4}$ " long Dowel Pin	680A	Mold Wiper Arm Cam Adjusting Set Screw
689	Slag Carrier Gear Stud		



Crucible Operating Mechanism - Plate No. 7


Part No.	Description	Part No.	Description
100	Main Frame (not sold)	2345	Crucible Swivel Bracket
15A	Oiler—Straight Threaded $\frac{1}{8}$ "-32 with cover	2341 $\frac{1}{2}$	Swivel Bracket Lock
16	Main Shaft (sold only as assembly A-18)	236	$\frac{1}{16}$ "-13 x $1\frac{1}{2}$ " long Hexagon Socket Cap Screw
22	No. 6 Taper Pin— $2\frac{1}{2}$ " long	237	Crucible Swivel Bracket Adjusting Screw
25	Woodruff Key—Size "G"	236E	Crucible Casting (Electric) (not sold separately—see part 205-EB)
28	$\frac{1}{2}$ "-18 Standard Jam Nut	240A	Crucible Casting Hinge Pin
64	$\frac{1}{2}$ " Bolt Size x $1\frac{1}{2}$ " OD Washer	242	Crucible Casting Dowel Pin
68	$\frac{1}{16}$ " Dia. x $\frac{1}{2}$ " long Center Pin	A247F	Crucible Mountpiece
95	$\frac{1}{4}$ "-16 Hexagon Nut	248	No. 10-30 x $\frac{1}{2}$ " long Phillips Head Screw
194 $\frac{1}{2}$	Main Shaft Bearing Oil Tube	250	$\frac{1}{4}$ "-20 x $\frac{1}{2}$ " long Hexagon Socket Cap Screw
205EB	Electric Crucible (sold as assembly A-205-EB-2)	A251AE-1	Electric Crucible Plunger Assembly, consisting of Plunger, Pin and Link
210	Crucible Cam Horizontal Roll Shaft	254B	Plunger Cam
210B	Crucible Adjusting Bolt	258	Plunger Cam Lever
214A	Crucible Adjusting Bolt Nut	259	Plunger Cam Lever Fulcrum
A215A	Crucible Adjusting Bolt Guard	260	Plunger Cam Lever Bracket
216	No. 8-36 x $\frac{1}{4}$ " long Round Head Screw	A264-1	Plunger Spring Sub-Assembly
217A	Crucible Spring	270A	Plunger Spring Connecting Swivel
218A	Crucible Spring Washer	270 $\frac{1}{2}$	Plunger Spring Connecting Screw
219	$\frac{1}{4}$ " Dia. x $1\frac{1}{4}$ " long Center Pin	271EA	Plunger Connecting Rod
220A	Crucible Cam	271 $\frac{1}{2}$	Plunger Spring Block
220	Crucible Cam Horizontal Roll	272	Plunger Connecting Rod (Lower)
224ED	Crucible Cam Lever (Electric)	273	Plunger Connecting Rod Washer
225A	Crucible Cam Lever Fulcrum	274A	Plunger Connecting Lever
225 $\frac{1}{2}$	Crucible Cam Lever Oil Tube	275	Plunger Connecting Lever Pin (Rear)
226D	Crucible Cam Roll Frame	276	Plunger Connecting Lever Bracket
226E	$\frac{1}{4}$ "-20 x $\frac{1}{2}$ " long Flat Head Screw	277	Plunger Connecting Yoke Cam Lever Stop Pin
229 $\frac{1}{2}$	$\frac{1}{4}$ "-20 x 1" long Round Point Square Head Set Screw	278	Plunger Connecting Yoke
230	$\frac{1}{4}$ "-20 Standard Jam Nut	279	$\frac{1}{4}$ " Dia. x $1\frac{1}{2}$ " long Ball Pin
231B	Crucible Swivel	280	Plunger Connecting Yoke Pin (Front)
232	Crucible Swivel Nut	281	Plunger Connecting Lower Pin Holder
233	Crucible Swivel Nut Pin		

Greifbik Operating Mechanism - Plate No. 7

Part No.	Description	Part No.	Description
282	Plunger Connecting Lever Holder Stud	702	$\frac{3}{16}$ "-18 x $1\frac{1}{2}$ " long Oval Point Slotted Headless Set Screw
286	Plunger Cam Lever Shoe	956B	$\frac{1}{2}$ " dia. x 1" long Ball Pin
287	Plunger Cam Lever Shoe Screw	969A	$\frac{1}{2}$ "-20 x $\frac{3}{8}$ " long Half Dog Point Hexagon Socket Set Screw
288	$\frac{3}{4}$ "-16 Hexagon Nut	1231A	$\frac{3}{8}$ "-16 x $1\frac{1}{2}$ " long Cap Point Hexagon Socket Set Screw
289	Plunger Cam Lever Roll	1333	$\frac{1}{2}$ "-20 x $\frac{1}{2}$ " long Cap Point Hexagon Socket Set Screw
290	Plunger Cam Lever Roll Stud	3285	$\frac{1}{4}$ " x 90° Special Street Elbow
302	$\frac{3}{4}$ "-18 Standard Jam Nut	3601	$\frac{3}{8}$ "-16 x $1\frac{1}{2}$ " long Hexagon Socket Head Cap Screw
625A	$\frac{1}{2}$ "-20 x $\frac{3}{8}$ " long Oval Point Self-Locking Hexagon Socket Set Screw	743A	$\frac{3}{8}$ "-16 x $1\frac{1}{2}$ " long Hexagon Socket Head Cap Screw
632	$\frac{3}{16}$ " dia. x $1\frac{1}{2}$ " long Cotter Pin		
742A	Safety Shaft		
744	No. 2 Taper Pin— $1\frac{1}{2}$ " long		
753A	Safety Flange		

Electric Crucible Cross Section - Plate No. 8

Part No.	Description	Part No.	Description
68	$\frac{1}{16}$ " dia. x $\frac{3}{4}$ " long Center Pin	233E	Electric Crucible Flanger Link (not sold separately—sold as part of assembly A-251-RE-1)
201EA	Bottom Casing Cover	271EA	Flanger Connecting Rod
205EB	Electric Crucible (sold as assembly A-205-EB-2)	274A	Flanger Connecting Lever
209EB	Electric Crucible Unit Clamp	276	Flanger Connecting Lever Bracket
209½	Electric Crucible Heater Spacer	280	Flanger Connecting Yoke Pin—Front
210	Crucible Cam Horizontal Roll Shaft	281	Flanger Connecting Lever Pin Holder
A211EA	Electric Crucible Heater—Right Hand (Specify Voltage)	281EC	Mouth Unit Cover
A212EA	Electric Crucible Heater—Left Hand (Specify Voltage)	286E	Mouth Unit Cover Screw
213B	Crucible Adjusting Bolt	290E	$\frac{3}{16}$ "-18 x 1" long Cap Point Hexagon Socket Headless Set Screw
216	No. 8-36 x $\frac{1}{4}$ " long Round Head Screw	291EA	Throat Cover
217A	Crucible Spring	A305EB	Crucible Wiring Assembly
218A	Crucible Spring Washer	A305EC	Mouth Heater (Specify Voltage)
224ED	Electric Crucible Cam Lever	A305EC	Crucible Throat Heater Assembly (Specify Voltage)
225A	Crucible Cam Lever Fulcrum	307E	Magnesium Content
225½	Crucible Cam Lever Oil Tube	308E	Throat Cover Pad
226D	Crucible Cam Roll Frame	309EC	Terminal Box (sold only as assembly A-302-EC)
226½	$\frac{3}{8}$ "-16 Slotted Hexagon Nut	302½E	Ovaltube Gaskets
227½	$\frac{3}{8}$ " hole dia. x $\frac{3}{4}$ " OD x $\frac{1}{16}$ " thick Steel Washer	309EB	Terminal Box Cover (sold only as part of assembly A-302-EC)
229½	$\frac{1}{4}$ "-20 x 1" long Round Point Square Head Set Screw	304½E	Terminal Box Mounting Washer
230	$\frac{1}{4}$ "-20 x $\frac{1}{16}$ " thick Standard Jam Nut	A400EB	Lowflow Dual Indicating Thermostat
230E	Electric Crucible Casing (not sold separately see part 205EB)	403	Thermostat Bracket
A247F	Crucible Mouthpiece	404	Thermostat Bracket Plate
250	$\frac{1}{4}$ "-20 x $\frac{3}{4}$ " long Hexagon Head Cap Screw	A438EA	Thermostat Mercury Tube
251A	Flanger (not sold separately—sold as A-251-RE-1)	573	$\frac{3}{16}$ "-18 x 1" long Flat Filister Head Screw
252	$\frac{3}{16}$ " dia. x $\frac{3}{4}$ " long Hardened Dowel Pin (not sold separately)	1219	No. 10-32 x $\frac{3}{4}$ " long Round Head Screw
		1466½	$\frac{1}{4}$ "-20 x $\frac{3}{4}$ " long Filister Head Cap Screw
		3916	No. 10-32 x $\frac{3}{4}$ " long Flat Head Hexagon Socket Cap Screw



DUAL INDICATING THERMOSTAT.

Dual Indicating Thermostat - Plate No. 2

Part No. Description

A400E Dual Indicating Thermostat


A410 $\frac{1}{2}$ EA Thermostat Microswitch


Part No.


Description

A418EA Thermostat Mercury Tube

421E Mercury Element Flange








Mold Cooling System - Plate No. 12

Part No.	Description	Part No.	Description
M1268	Water Cooled Mold Connector	M307	Mold Connection Adapter
M1132	No. 8-32 x 1/2" long Oval Fillet Head Screw	M308A	Water Hose Frame Clamp
M1171A	Water Cooled Mold Copper Tube Compression Sleeve	M309A	Water Hose Strap Clamp
M1124	Water Cooled Mold Copper Tube Connection Nut	M315	Mold Connection Adapter Clip
AM180A	Water Cooled Mold Hose Clamp	AM400	Low Voltage Water Cooler—Specify Voltage
221E	No. 10-24 x 1/2" long Round Head Screw	DS494	1/2" x 18 x 1/2" long Cap Point Hexagon Socket Set Screw
M308B	Water Hose		







MAIN SHAFT PARTS

Main Shaft, Cam and Safety Mechanism — Top View — Plate No. 13

Part No.	Description	Part No.	Description
15A	Gilt	605	Main Slide Cam (Sold only as A605)
18	$\frac{1}{4}$ "-20 x $\frac{1}{2}$ " long Flat Fillister Head Screw	A605	Main Slide Cam Assembly (Includes 605 and 627)
20	$\frac{1}{4}$ "-13 x 2" long Hexagon Socket Cap Screw	606	Main Slide Gib (Front) (Use Dowel No. 425, Screws No. 503 & Adjust- ing Screws No. 604A)
21	Main Shaft Collar (Right)	627	Bottom Trim Cam (Sold only as A605)
22	No. 6 Taper Pin— $2\frac{1}{2}$ " long	628	Bottom Trim Cam Bolt
22½	No. 6 Taper Pin— $2\frac{1}{2}$ " long	629	Bottom Trim Cam Ball Stud
23	Main Shaft Collar (Left)	630	Bottom Trim Lever
25	"O" Woodruff Key (Used on 250A, 254B, A605 & A647) (Not Illustrated)	631	Bottom Trim Lever Fulcrum
50	$\frac{1}{8}$ "-13 x $\frac{1}{4}$ " thick Standard Jam Nut	632	$\frac{1}{2}$ " dia. x $1\frac{1}{2}$ " long Corner Pin
85A	Table Latch Yoke Pin	634	Bottom Trim Lever Oil Tube
85½	Table Latch Safety Block (Use Pin 86½)	A647	Ejector Cam and Delivery Cam Assembly (Includes 647 and 656)
91B	Table Latch Yoke	647	Ejector Cam (sold only in assembly A647)
A91B	Table Latch Yoke Assembly (Consists of Yoke (91B), Safety Block 189½) and Yoke Pin (85A)).	651C	Delivery Slide Lever
180½A	Oil Cap (Threaded)	652B	Delivery Slide Lever Fulcrum Bolt
184B	Main Shaft Bearing (Right) Oil Tube	653A	Delivery Slide Lever Fulcrum Nut
184A	Main Shaft Bearing Oil Tube	656	Delivery Cam—(Sold in A647 Assembly only)
190½	Main Shaft Bearing Oil Tube	657A	Delivery Cam Roll
220A	Grindlife Cam (Use Key No. 25)	658B	Delivery Cam Ball Stud
248	10.00 x $\frac{1}{2}$ " long Flat Fillister Head Screw	669½	Stationary Delivery Slide Controller
254B	Hanger Cam (Use Key No. 25)	671½	Delivery Cam Roll Washer
A25B	Hanger Cam Lever Assembly (Includes 95, 266, 267, 269 and 290)	731	No. 2 x 1" long Taper Pin
276½	Fund Box Bracket Slide	737B	Safety Chuck (Lower) (See Plate No. 16)
277EB	Fund Box Bracket	742A	Safety Shaft
285	$\frac{1}{8}$ " Bolt Size x $1\frac{1}{2}$ " OD x $\frac{1}{2}$ " thick Lock Washer	750½	Lower Safety Shaft Spring
600	Main Slide Gib (Back) (Use Dowel No. 425 and Screws No. 602A)	753A	Safety Finger
601	Main Slide Gib (Back L.H.) (Use Dowel No. 425 and Screws No. 604A)	754½	Spring Shield
		755½	Spring Post
		1333	$\frac{1}{4}$ "-20 x $\frac{1}{2}$ " long Hexagon Socket Set Screw




MAIN SLIDE

Main Slide - Plate No. 14

Part No.	Description	Part No.	Description
69	1/2"-11 Jam Nut (3/4" across flats)	616 1/2	Main Slide Adjusting Screw Check Nut (Upper)
64	Washer for 1/2" Bolt	617	Main Slide Spring Bar
73	Table Latch Operating Stud Bracket	619	Main Slide Mold Screw
77	Table Latch Operating Stud	620A	Bottom Trim Slide
158	1/2" Slotted Washer	621	Bottom Trim Slide Rail
171	1/2"-20 x 3/8" long Flat Filler Head Screw	622A	Bottom Trim Slide Roll Stud
216	3-36 x 1/4" long Round Head Screw	623	Bottom Trim Slide Gib
M216	Washer for 1/4" Bolt	625A	1/4"-20 x 3/4" long Self-Locking Oval Point Socket Set Screw
341 1/2	1/2"-20 x 3/8" long Hexagon Socket Cap Screw	625 1/2	1/4"-20 x 3/4" long Self-Locking Oval Point Socket Set Screw
357	Washer for 3/8" Bolt	631	Ejector Slide Gib Guard
360 1/2	Main Slide Oiler	633	Bottom Trim Knife
425	1/2" round x 1/2" long Dowel Pin	AS284	Ejector Blade Assembled (5-point)
531	Locking Release Tripper Stud (Main Slide)	641	Ejector Clamp
557	3/16" round x 3/4" Hardened Dowel Pin	642	3/8"-16 x 3/4" long Hexagon Head Cap Screw
557 1/2	Bottom Trim Slide Gib Screw	643B	Ejector Slide
680	Main Slide	644	Ejector Slide Gib
689	Main Slide Cam Roll	646	Ejector Cam Roll
610A	Main Slide Cam Roll Stud	648A	Ejector Cam Roll Stud
611	Main Slide Dowel	690	1/4"-20 x 1/2" long Flat Filler Head Screw
612A	Main Slide Adjusting Plate	999 1/2	1/4"-20 x 3/4" long Half Dog Point Socket Set Screw
612B	Main Slide Adjusting Plate Screw	1680 1/2	10-32 x 3/8" long Cap Point Headless Set Screw
614	Main Slide Adjusting Screw		
615	Main Slide Adjusting Screw Check Nut		
625 1/2	1/4" Plain Lock Washer		
636	Main Slide Spring		

Main Slide Parts - Plate No. 15


Part No.	Description	Part No.	Description
64	Style 203, 1/4" Washer x 3/16" thick	611	Main Slide Dowel
216	Style 1, No. 8-36 Round Head Screw x 1/2" long	613A	Main Slide Adjusting Plate Screw
531	Locking Release Tripper Stud		Main Slide Adjusting Plate Screw Washer— Use 64
557 1/2	Bottom Trim Slide Gib Spacer Screw —Use with Lock Washer 185	614	Main Slide Adjusting Screw
583	Style 4, No. 10-30 Headless Set Screw x 1/4" long	615	Main Slide Adjusting Screw Check Nut
600	Main Slide (must be sold fitted with part 620-A) Main Slide Offer—Use 303 1/2		Main Slide Adjusting Screw Lock Washer— Use 615 1/2
601	Main Slide Gib (back)	615 1/2	Style 202, 3/8" Plain Lock Washer
	Main Slide Gib Dowel Pin—Use 425	616	Main Slide Spring (box of 4)
602A	Main Slide Gib Adjusting Screw	616 1/2	Main Slide Adjusting Screw Check Nut (upper)
603	Main Slide Gib (back left hand)	617	Main Slide Spring Bar
	Main Slide Gib Dowel (back left hand)—Use 425		Main Slide Spring Bar Screws—Use 608
604A	Main Slide Gib Adjusting Screw (back left hand)	618	Main Slide Spring Anchor
605	Main Slide Gib (front)	619	Mold Screws
	Main Slide Gib Dowel Pin (front)—Use 425	620A	Bottom Trim Slide Adjusting Screw
	Main Slide Gib Adjusting Screw (front top)— Use 583	620 1/2	Ejector and Bottom Trim Slide Adjusting Screw
	Main Slide Gib Adjusting Screw (front)— Use 604A	626	Style 5, 1/4"-20 Square Head Set Screw x 1/2" long
609	Main Slide Cam Roll	631	Ejector Slide Gib Guard
610A	Main Slide Cam Roll Stud		Ejector Slide Gib Guard Screws—Use 216
	Main Slide Cam Roll Stud Set Screw—Use 626	696	Style 1, 1/4"-20 Fillister Head Screw x 1/2" long



Ejector and Bottom Trim Slide Parts

Ejector and Bottom Trim Slide Parts - Plate No. 28

Part No.	Description	Part No.	Description
59	Style 182, $\frac{1}{2}$ "-13 Thick Hexagon Jam Nut x $\frac{1}{8}$ " thick		Bottom Trim Slide Gib Screw Washer—Use 138
173	Style 1, $\frac{1}{4}$ "-20 Fillister Head Screw x $\frac{3}{8}$ " long	633	Bottom Trim Knife
M216	Hex. Nut		Bottom Trim Knife Screws—Use 173
257	Ejector Clamp Washer	A600A	Ejector Blade Assembled
326	Style 86, $\frac{3}{16}$ " Dowel Pin x $\frac{3}{8}$ " long	641	Ejector Clamp
425	Style 86, $\frac{1}{8}$ " Dowel Pin x $\frac{1}{2}$ " long	642	Ejector Clamp Screw
557	Style 86, $\frac{3}{16}$ " Dowel Pin x $\frac{3}{8}$ " long	643B	Ejector Slide
625A	Bottom Trim Slide (not sold separately—see part 600)	644	Ejector Slide Gib
	Bottom Trim Slide Oiler—Use 303 $\frac{1}{2}$	648	Ejector Slide Gib Pin—Use 557
621	Bottom Trim Slide Roll	649A	Ejector Cam Roll
622A	Bottom Trim Slide Roll Stud		Ejector Cam Roll Stud
623	Bottom Trim Slide Gib	1803 $\frac{1}{2}$	Ejector Cam Roll Stud Nut—Use M216
	Bottom Trim Slide Gib Screws—Use 557 $\frac{1}{2}$		Bottom Trim Slide Roll Stud Set Screw




(8006)

MOUTHPIECE WIPER AND
BRACKET ASSEMBLY

Mouthpiece Wiper - Plate No. 17

Part No.	Description	Part No.	Description
M132	8-32 x 3/4" long Oval Fillister Head Screw	805D	Mouthpiece Wiper Felt (Sold as A805D—Box of 25)
6423/4A	10-30 x 7/8" long Round Head Screw	805 1/2	3/16" dia. x 3/16" Round Pin
801	Mouthpiece Wiper Latch Pinset Screw	806K	Mouthpiece Wiper Bracket
801 1/2	Mouthpiece Wiper Frame Spacer	A807 1/2	Mouthpiece Wiper Frame Assembly
802	Mouthpiece Wiper Hinge Block Screw	808 1/2	Mouthpiece Wiper Frame Spacer Pin
802 1/2	Mouthpiece Wiper Tongue Hinge Block	809 1/2	Mouthpiece Wiper Tongue and Hinge Block Rivet
803	Mouthpiece Wiper Latch Screw	811 1/2	Mouthpiece Wiper Hinge Pin
803 1/2	Mouthpiece Wiper Latch	812 1/2	Mouthpiece Wiper Hinge
804	Mouthpiece Wiper Tongue Pin		
A804 1/2	Mouthpiece Wiper Tongue Assembly		





Accessories, Tools and Supplies

Accessories, Tools and Supplies - Plate No. 18

Part No.	Description	Part No.	Description
M179 $\frac{1}{2}$ B	Open End Wrench ($\frac{1}{4}$ " and $\frac{1}{2}$ " openings)	A353	Blank Slug Block
M180 $\frac{1}{2}$ A	Open End Wrench ($\frac{1}{8}$ " and $\frac{1}{16}$ " openings)	958	Mold Removing Handle
AM254	Soluble Oil ($\frac{1}{4}$ pint)	963	Hemagon Wrench
A304	Mouthpiece Opening Shield	964	Main Slide Adjusting Screw and Nut Wrench
900	Offset Screwdriver	A966B	Mouthpiece Screw Removing Tool Assembled
A332A	Electric Testing Lamp Complete	8870A	Matrix Stick Lock Assembled
A339B	Mouthpiece Slot Scraper	8902A	Flange Holder - Well Cleaning Tool Holder Assembled
A339 $\frac{1}{2}$ B	Crossfile Thread Scraper	8902 $\frac{1}{2}$ A	Well Cleaning Tool Assembled
945	Mouthpiece Wire Brush	8FG998A	Hot Metal Thermometer (Fahrenheit)
A945A	Ladle "Lubricant" Fluid (1 quart)	8FG999 $\frac{1}{2}$ A	Hot Metal Thermometer (Centigrade)
A945B	Ladle "Lubricant" Fluid (1 gallon)	1285	End Wrench ($\frac{1}{8}$ " and $\frac{1}{4}$ " openings)
A945C	"Lubricant" Fluid Swab		

Case No.	Age	Sex	Occupation	Duration of Illness	Chief Complaint	Diagnosis	Course	Result
1	35	M	Teacher	2 weeks	Headache, dizziness	Migraine	Improved	Recovered
2	42	F	Homemaker	1 month	Weakness, fatigue	Anemia	Improved	Recovered
3	28	M	Student	3 weeks	Stomach pain, nausea	Gastritis	Improved	Recovered
4	55	F	Retired	6 months	Joint pain, stiffness	Rheumatism	Improved	Recovered
5	30	M	Engineer	4 weeks	Shortness of breath	Emphysema	Improved	Recovered
6	60	F	Widow	1 year	Weight loss, weakness	Tuberculosis	Improved	Recovered
7	40	M	Farmer	2 months	Back pain, numbness	Sciatic neuritis	Improved	Recovered
8	25	F	Teacher	3 weeks	Blurred vision	Glaucoma	Improved	Recovered
9	50	M	Businessman	5 months	Heart palpitations	Coronary artery disease	Improved	Recovered
10	38	F	Homemaker	2 months	Irregular menstruation	Menstrual disorder	Improved	Recovered



